

Attn. Geoff Proud
 Main West Coast Road
 Sheffield S18 7LJ
 CANTERBURY
 Ph. 03 318 3824
 Fax 03 318 3646
 Mob. 0276 872 339
 Email geoff@taege.com
 www.taege.com


COLOUR CODES FOR SENSOR WIRING

	Standard					
+12 Volt	Brown	Red	Red	Red	Red	Left
Signal	Black	Yellow	White	White	Brown	Centre
Ground	Blue	Black	Black	Blue	Black	Right

The standard colours are Brown/Black/Blue on the sensors we use now. Look along the table to the colour mix of the sensor you want to fit or replace and fit the wires in the place of the standard colours.

Front Box of Double Box Drill


This can also be a single box but it wouldn't have the red and black wires doubled up as that is the feed for the back box.



Motor sensor

Jockey Wheel sensor

Back Box of Double Box



Main power
10 Amp Fuse

Computer
system 2 Amp
fuse

Blue

Black

Brown

Both sensors are wired up the same with the colours moving away from the motor. Blue, Black, Brown.

Positive 12V supply
from tractor or battery

Positive 12V feed to
motor


Negative 12V feed to
motor

Negative 12V supply
from tractor or battery

Both of these
should be
covering the 2
pins closest to
the green 3 pin
blocks.

Front Box of Double Box Drill

This can also be a single box but it wouldn't have the red and black wires doubled up as that is the feed for the back box and the white and brown wires aren't used.



Up until recent times we have had separate wires with 12V supply and 7 core flex going to each box.

Now we are running a thicker dual core wire carrying the 12V supply to the front box, joining it there and then running it to the back box.

A single 7 core flex runs from the computer plug to the front box, is joined there and then runs to the back box.

BLACK to front box joins with black to back box.

Yellow to front box from main wiring Empty slot

Green to front box from main wiring


Blue to front box from main wiring

Red from front box joins with red to back box.

White from front box wiring joins with blue to back box.

Brown from front box wiring joins with yellow to back box.

Back Box of Double Box



With the computer plugged in and turned on the following should occur.

This LED shows the pulse from the wheel sensor and it should flash when the jockey wheel is rotated. (Front or single box only)

This LED shows the pulse from the motor sensor and it should flash when the motor wheel is rotated.

This LED shows there is 12V power getting to the system and should glow continuously whenever the 12V supply is connected (even if the computer isn't plugged in)


This LED shows there is a signal coming from the computer to the motor. This should glow continuously when the jockey wheel is rotated with the computer in the RUN mode.

This LED isn't used at present on drills fitted with a jockey wheel so it doesn't glow at any time.

On earlier drills without a jockey wheel that are still using the proximity switch mounted above the axle the following applies.

This LED shows the switch is operating correctly and it should glow continuously when the drill is lowered into the drilling position and should go out when the drill is lifted out of the ground.

Single Box




SEE OTHER PAGES FOR WIRING OF A 4 BLOCK I/O BOARD AND A 2x3 BLOCK I/O BOARD

Jockey Wheel sensor

Motor sensor

WIRING DIAGRAM FOR CONVERTING PLUGS FROM OLD COMPUTER SYSTEM TO NEW




- Connect both black wires going to **FRONT & BACK** box
- Connect brown wire going to **BACK** box only
- Connect yellow wire going to **FRONT** box only
- Connect white wire going to **BACK** box only
- Connect green wire going to **FRONT** box only
- Connect blue wire going to **FRONT** box only
- Connect both red wires going to **FRONT & BACK** box

To Alter Wiring on an Existing Double Box Drill to accommodate the new RC 300 Computer Do The Following

1. Determine which 7 core flex goes to which box.
2. Remove the connecting plugs going to both boxes.
3. Cut the Yellow, Green, & Blue wires going to the **BACK** box only.
4. Cut the Brown & White wires going to the **FRONT** box only.
5. Connect both **BLACK** wires going to **FRONT & BACK** box to the **SIGNAL RIGHT** position of the plug.
6. Connect the **BROWN** wire going to the **BACK** box to the **TAIL** position of the plug.
7. Connect the **YELLOW** wire going to the **FRONT** box to the **REVERSE** position of the plug.
8. Connect the **WHITE** wire going to the **BACK** box to the **EARTH** position of the plug.
9. Connect the **GREEN** wire going to the **FRONT** box to the **SERVICE** position of the plug.
10. Connect the **BLUE** wire going to the **FRONT** box to the **BRAKE** position of the plug.
11. Connect the **WHITE** wire going to the **BACK** box to the **REVERSE** position of the plug.
12. Connect both **RED** wires going to **FRONT & BACK** box to the **SIGNAL LEFT** position of the plug.

For *single box* wiring no change should be necessary. Wires should be fitted to suit the computer plug shown above.



4 BLOCK SENSOR WIRING

- BLUE** Join both blue wires from both sensors.
- BLACK** from jockey wheel sensor to 2nd point away from motor
- BROWN** Join both brown wires from both sensors
- BLACK** from motor sensor to 4th point away from motor

This picture shows the wiring of a single box or the front box of a double drill with a 4 block sensor connection.

For the back box of a double drill wire it up as per the code and just leave the 2nd connection away from the motor empty.